



YXZ1000R/SS Glove Box Knob and Lock Kit Installation Instructions

All Years

Please read entire instruction sheet before beginning



Disclaimer

By purchasing, installing, or using any product from Solex Offroad, the customer acknowledges and accepts full responsibility for any risks associated with its use. Solex Offroad and Solex Enterprises LLC are not liable for any damages, injuries, accidents, losses, or deaths that may result from the installation, use, or misuse of its products. Offroad powersports is an inherently dangerous activity that involves significant risks, including but not limited to collisions, rollovers, mechanical failures, unpredictable terrain conditions, and operator error. The purchaser assumes all risks and responsibilities associated with operating a vehicle equipped with Solex Offroad products.

All products must be installed correctly and inspected regularly to ensure proper function and safety. Installation should be performed by a qualified professional or an individual with adequate mechanical knowledge. By purchasing and using Solex Offroad products, the customer expressly waives any claims against Solex Offroad and Solex Enterprises LLC, their owners, employees, affiliates, and distributors for any liability, injury, or loss incurred. If you have any questions about product safety, installation, or usage, please contact Solex Offroad before proceeding.

Parts List

(1) Glove Box Knob



(1) Lug Adapter



(1) Locking Latch



(1) Detent Pin



(1) Detent Pin Spring



(1) M6x20mm bolt




Installation Instructions

1. Open the glove box door and ensure any contents which may interfere with installation are removed. Remove the OEM glove box latch from the back-side. Two small tabs on either side of the lock lever will need to be overcome to separate the OEM lever and front knob. NOTE: the small locking tabs may break from removal. Neither the locking latch or knob will be reused.



2. Once the OEM lock assembly is removed, thoroughly clean the area to ensure no debris is present. Ensure the riveted washers are clean - both on the front and back.



3. Identify the low shoulder in one of the three lug valleys on the lug adapter (circled in RED below). Place the lug adapter through the front of the glove box with the low shoulder facing downwards (indicated by BLUE arrow).

Find low shoulder in one of the lug valleys




Place lug adapter through front with low shoulder pointing down



4. Push the Glove Box Knob onto the front of the adapter with the raised arrow (circled in BLUE) pointing upwards. NOTE: The knob may have a slight tight fit on the lug adapter. Excessive force should not be used to install.




5. Place the detent pin spring into the hole on the locking latch.
Place the detent pin on top of the spring. **WARNING: DO NOT PUSH THE PIN DOWN AND RELEASE. THE DETENT PIN WILL BE EJECTED AT HIGH SPEED AND MAY CAUSE INJURY.**



6. Slide the locking latch assembly onto the lug adapter from the back side. Note the raised portion where the detent pin is held engages with the lowest shoulder on the lug adapter identified in step 3. **Important: The detent pin should fall into the slot on the backside of the glove box, contacting the backside of the front washer.** NOTE: the detent pin and spring may need to be held in place until the locking lever assembly is slid on far enough to trap the detent pin. Push the locking assembly all the way into place until it bottoms out against the locking lug.

Note detent pin assembly dropped into slot on backside



7. Once the locking lever assembly has been pushed on, install the M6x20mm bolt through the center of the assembly. Tighten with a small 8mm wrench or socket. Tighten until snug - do not over tighten. If the assembly is hard to rotate, then the bolt likely needs to be loosened up slightly. The assembly should rotate smoothly with a slight detent click.



8. Your SOLEX Offroad YXZ 1000 Glove Box Knob and Lever kit is now installed.

If you have any questions, please reach out to
solex.enterprises24@gmail.com

These instructions are not for redistribution or copy unless otherwise approved by Solex Enterprises LLC.