



YXZ1000R-SS XTR SE Center Light Lift Brackets
Years: 2019+



Disclaimer

By purchasing, installing, or using any product from Solex Offroad, the customer acknowledges and accepts full responsibility for any risks associated with its use. Solex Offroad and Solex Enterprises LLC are not liable for any damages, injuries, accidents, losses, or deaths that may result from the installation, use, or misuse of its products. Offroad powersports is an inherently dangerous activity that involves significant risks, including but not limited to collisions, rollovers, mechanical failures, unpredictable terrain conditions, and operator error. The purchaser assumes all risks and responsibilities associated with operating a vehicle equipped with Solex Offroad products.

All products must be installed correctly and inspected regularly to ensure proper function and safety. Installation should be performed by a qualified professional or an individual with adequate mechanical knowledge. Solex Offroad products are sold with a limited warranty covering defects in materials and workmanship for a period of 1 year from the date of purchase. This warranty does not cover damages resulting from improper installation, modification, normal wear and tear, or use in extreme conditions.

By purchasing and using Solex Offroad products, the customer expressly waives any claims against Solex Offroad and Solex Enterprises LLC, their owners, employees, affiliates, and distributors for any liability, injury, or loss incurred. If you have any questions about product safety, installation, or usage, please contact Solex Offroad before proceeding.

Parts List

(2) Center Light Lift Brackets



(2) M6x40mm bolts



Note: bolts may come installed into brackets.

Installation Instructions


1. Remove the bolts holding the center lights to the frame brackets (circled in the below image).



2. Install the center light lift brackets onto the bottom of the light pods. Ensure the label "SOLEX" is facing the front of the machine. You can unplug and remove the center lights from the SxS if it makes this process easier. Tighten the M6x40mm bolt, but do not overtighten. This bolt may be a little tight installing - this is normal.



Front





3. Install the light pod with the lift bracket back onto the SxS mounting brackets. Utilize the OEM bolts removed in step one. Tighten up the bolts to secure the light pod assembly, but do not overtighten. If the center light pods were removed from the SxS, plug them back in.
4. Your center light pod lift brackets are now installed.

These instructions are not for redistribution or copy unless otherwise approved by Solex Enterprises LLC.