



Teryx S 800 INSTALLATION

Years: 2021+

S MODEL ONLY



These instructions are not for redistribution or copy unless otherwise approved by Solex Enterprises LLC.

Disclaimer

By purchasing, installing, or using any product from Solex Offroad, the customer acknowledges and accepts full responsibility for any risks associated with its use. Solex Offroad and Solex Enterprises LLC are not liable for any damages, injuries, accidents, losses, or deaths that may result from the installation, use, or misuse of its products. Offroad powersports is an inherently dangerous activity that involves significant risks, including but not limited to collisions, rollovers, mechanical failures, unpredictable terrain conditions, and operator error. The purchaser assumes all risks and responsibilities associated with operating a vehicle equipped with Solex Offroad products.

All products must be installed correctly and inspected regularly to ensure proper function and safety. Installation should be performed by a qualified professional or an individual with adequate mechanical knowledge. By purchasing and using Solex Offroad products, the customer expressly waives any claims against Solex Offroad and Solex Enterprises LLC, their owners, employees, affiliates, and distributors for any liability, injury, or loss incurred. If you have any questions about product safety, installation, or usage, please contact Solex Offroad before proceeding.

These instructions are not for redistribution or copy unless otherwise approved by Solex Enterprises LLC.

Parts List

* = Parts Included with Boot Guard Kit

(1) Left Boot Guard



(1) Right Boot Guard



(4) Bolts, Short (M6 x 12mm)



These instructions are not for redistribution or copy unless otherwise approved by Solex Enterprises LLC.

Installation Instructions

1. Make sure the lower A-Arm brace is clean and free of debris.



These instructions are not for redistribution or copy unless otherwise approved by Solex Enterprises LLC.

2. Set the right boot guard into the right lower A-Arm brace.



3. The guard should slide right into place, and fit snug into the right lower A-Arm.



These instructions are not for redistribution or copy unless otherwise approved by Solex Enterprises LLC.

4. Insert the 2 M6 bolts through the bottom of the A-Arm and screw into the boot guard. Once both bolts are inserted hand tight, torque the bolts to **36 inch pounds**.



5. Repeat steps 1-4 for the left side.

These instructions are not for redistribution or copy unless otherwise approved by Solex Enterprises LLC.